PURE ESSENTIAL OIL WORKS

CHRISTMAS TREE

LED Ultrasonic Aroma Diffuser

IMPORTANT INSTRUCTIONS — RETAIN FOR FUTURE USE

Congratulations on your purchase of the Pure Essential Oil Works Christmas Tree LED Ultrasonic Aroma Diffuser. Please read the instructions and safety tips before use. Your diffuser comes with a one-year limited warranty. If for any reason you need service, please call 800-520-6000.

This Aroma Diffuser uses ultrasonic waves to instantly vaporize water and essential oil in the tank, to produce a cool, fragrant mist.





OPERATION

1.

1. Remove the silicone cover vertically, then remove the inner cover by twisting counter-clockwise.

2.

2. Add the required amount of water into the tank, using the provided measuring cup, 2-3 drops of essential oil is better for 100ml of water.

3.

3. Replace inner cover and silicone cover.
Plug in the adapter to the power supply and switch on.

4. "LIGHT" button function
A. Press button one time will cascade through all LED light colors.
B. Press button more than once will change to a single LED light color.
C. Press and hold button to turn off LED light.

4~5.



5. "MIST" button function
A. Press button and green light above button is on indicating intermittent mist function, running and stopping every 30 seconds.
B. Press button and red light above button is on indicating continuous mist function.
C. Press button and light above button is off indicating mist is turned off.

ATTENTION

- The amount and intensity of mist produced will vary, but this is normal.
Factors that affect this include water type, humidity, temperature, air currents etc.
- If there is no water in the tank, pressing the "MIST" will cause the unit to "Beep" 3 times to remind you to add water. The unit will not work without water.
- Only 100% natural essential oil can be used in this product, those containing chemical fragrance, spice or impurities will cause malfunction. Add 2-3 drops per 100 ML water every time, too much oil will clog the system. Please clean the unit as per the maintenance instructions, before changing to a new type of essential oil.

ACCIDENTAL LEAKAGE

In the event of the unit being knocked over or tipped during use, please follow the steps as below to avoid malfunction:

- Unplug the unit and remove cover.
- Pour out any remaining water out of the tank.
- Shake the unit gently to drain any water inside the mechanism, then allow drying for at least 24 hours.



MAINTENANCE

After using 5-6 times or 2-3 days, please clean the product as follows:

- Unplug the unit from main supply and remove cover.
- Pour out any remaining water from the "**DRAIN SIDE**" of the tank.
- Put 1 tablespoon of citric acid in the water tank, add just under 100ml of warm water (up to 158°F).
- Soak for 5 minutes, and then drain solution from the "**DRAIN SIDE**" of the tank.
- Wipe with a soft cloth. Avoid ultrasonic vibration plate area, which can be gently cleaned with a cotton swab.
Never use other acids, enzymes or detergents, as this may risk poisonous gas to be created or cause malfunction.

Cover has an inner cover that can also be removed for cleaning.

1. Pull grip as indicated in the diagram to release.
2. After cleaning inner cover, replace by holding grip, and pressing down inner and outer cover until "click" is heard.



PRECAUTIONS

Please check below to avoid malfunction of the unit.

- Do not fill over 160 ML "**MAX**" at any time.
- Do not switch on power when the tank is empty.
- Do not touch the ultrasonic vibration plate.
- Clean regularly as per maintenance instructions to avoid malfunction.
- Always unplug from power supply before maintenance.
- For hygiene reasons, after use, pour water from "**DRAIN SIDE**" of tank and wipe with a clean dry cloth.
- Essential oil can stain, in the event of spillage or contact, please wipe away with a soft cloth.
- Do not let mist blow directly onto furniture, clothing, wall, etc.
- Keep away from direct sunshine, heat or fans.
- Always keep on stable flat surface and do not place on carpet, duvet or unstable area.
- Keep away from electronic equipment, such as TV and audio equipment.
- Do not tip the product. This may cause water to enter the mechanism and cause malfunction.
- Use tap water only, does not use mineral water, sparkling water, etc.
- The amount and intensity of mist produced will vary, but this is normal.
- Never move product when in use.
- Do not touch any part of the product with wet hands.
- Keep cord clear of pathways and do not pull forcefully at any point.
- If smoke or burning smell is detected, unplug immediately.

TROUBLESHOOTING

Please refer to the table below in the event of the product operating abnormally

Symptom	Possible Cause	Solution
Will not switch on-switch off early	• Is there enough water in the tank? • Is the power cord connected property?	• Add water to the tank • Disconnect, check cables and re-connect carefully.
No mist or abnormal mist	• Not enough water? • Too much water? • Dirt on the Ultrasonic plate? • Cover and inner cover are not installed properly? • Dirt on the air suction port on the underside of the base?	• Add suitable amount of water in the tank. • Water must never be filled over 160ML (MAX) line. • Please refer to Maintenance instructions Remove and re-install correctly, so vapors can be released freely. • Clean the air suction port of any dust. • Restricted airflow will affect mist.
Water leakage from product	• Cover and inner cover are not installed properly? • Has the unit been tipped over? • Low temperature or high humidity?	• Remove and reinstall correctly, so vapors can be released freely. • Follow accidental leakage instructions. • Under these conditions, the mist may condense quickly into water droplets.

SPECIFICATIONS

Dimensions	Approx. 6" Round x 9"H
Weight (excluding adapter)	Approx. 11.3 oz.
Power: Input/Output	AC100-240V 50/60HZ | DC 24V 0.65A
Length of cord	Approx. 5 ft.
Electric consumption	Approx. 10 W
Tank Capacity	5.4 oz. (160 ml)
LED light	5 Bulbs
Materials	Upper parts PP, Lower base ABS
Accessories	AC Adapter and measuring cup
Method of mist production	Ultrasonic vibration at approx. 2.4MHz

PURE ESSENTIAL OIL WORKS

Item #308578
pureessentialoilworks.com • 800.520.6000
tng worldwide • New Hudson, MI 48165
©2018 TNG • Made in China